ITIA Information Model Robot Lab Report

Stefan Adelmann (01633044) Hannes Brantner (01614466)

June 22, 2020

1 OPC UA Gateway

OPC UA Gateway				
Device:	RaspberryPi 3			
ID:	BCM2835 (a02082)			
MAC:	b8:27:eb:09:db:ca			
IP:	192.168.162.84/25			
Port:	4840			

2 Robot Controller

Robot Controller			
Device:	Robot Controller		
ID:	CR750-D		
MAC:	38:e0:8e:9e:89:8d		
IP:	192.168.162.82/25		
PORT:	10003		

3 I/O Mapping

Sensors				
Index	Description			
1	Robot handling module - workpiece alignment			
2	Robot handling module - workpiece in pick-up position			
3	Control panel - Start (make contact)			
4	Control panel - Stop (normally closed)			
5	Control panel - Reset (NO contact)			
7	Control panel - COM bridge (I7)			
8	Robot assembly module (spring magazine) - Slider retracted			
9	Robot assembly module (spring magazine) - Slide extended			
10	Module robot assembly (spring magazine) - spring available			
12	Robot assembly module (lid magazine) - Slide retracted			
13	Robot assembly module (lid magazine) - Slide extended			
15	Module robot assembly (lid magazine) - lid on tray			
900	Robot module (hand) - part not black			

Actuators			
Index	Description		
0	Control panel - Start (LED)		
1	Control panel - Reset (LED)		
2	Control panel - Q1 (LED)		
3	Control panel - Q2 (LED)		
4	Control panel - COM bridge (Q4)		
8	Robot assembly module (spring magazine) - Slide out		
12	Robot assembly module (lid magazine) - Slide out		

4 OPC UA Methods

OPC UA Methods							
Method	Description	ObjectId	MethodId				
ReadInput(Index)	Returns the Value of the input at the given Index	ns=4;i=1066	ns=4;i=1067				
WriteOutput(Index, Value)	Sets the output at the given Index to the given Value	ns=4;i=1066	ns=4;i=1111				
GetMostRecentError()	Returns the most recent error that occurred	ns=4;i=1103	ns=4;i=1105				
${\bf GetRecentErrors(NumberOfErrors)}$	Returns the last NumberOfErrors errors that occurred	ns=4;i=1066	ns=4;i=1140				
ResetError()	Resets the error state of the robot controller	ns=4;i=1102	ns=4;i=1108				
OpenGripper()	Opens the multi function gripper	ns=4;i=1130	ns=4;i=1131				
CloseGripper()	Closes the multi function gripper	ns=4;i=1130	ns=4;i=1134				
Move(X,Y,Z,A,B,C)	Translates the robot arm to the position (X,Y,Z) with the rotation (A,B,C)	ns=4;i=1130	ns=4;i=1137				
MoveToSafePosition()	Moves the robot arm into the predefined safety position	ns=4;i=1113	ns=4;i=1115				
RestartServer()	Reboots the OPC UA Gateway device	ns=0;i=2253	ns=4;i=1164				