

ITIA Target Programming (Robot) Lab Report

Stefan Adelman (01633044) and Hannes Brantner (01614466)

May 15, 2020

1 SysML Review

For the robot station in phase 2, no two SysML models had to be merged. The presented model from phase 1 of this lecture contains the whole station. As a self review we remodeled certain aspects of the robot station.

1.1 Parametric diagram

The parametric diagram that was created in phase 1 has no direct link to the real robot station. Distances do not need to be handled by the user in any way and the robot itself has sophisticated movement schemes pre-installed. Measurements between two points in 3D space therefore cannot be seen as a straight line. The diagram was dropped from the revised SysML model.

1.2 Internal Block Diagram

The diagram does not show the internal wiring of individual sensors and actuators. This was an deliberate choice to not overcrowd the diagram. Information on the internal wiring of the used connectors can be found in separate tables.

2 I/O Mapping

The following I/O mapping was created for the robot station.

2.1 Robot

Movement of the 6 axis robot arm, shown in 1 as well as the function of the multi-functional gripper is handled internally by the robot controller. The user does not need to define these I/O mapping themselves, instead the programming language Melfa uses commands shown in table 2.1 to actuate the arm. Additionally OPC UA methods are shown that execute the corresponding action.

| Melfa-Command | OPC UA | Beschreibung |
|------------------|-------------------|--|
| Mov(X,Y,Z,A,B,C) | move(X,Y,Z,A,B,C) | Modul Roboter (Hand) - Position, Rotation an- fahren |
| HOpen 1 | gripperOpen() | Modul Roboter (Hand) - Gripper öffnen |
| HClose 1 | gripperClose() | Modul Roboter (Hand) - Gripper schließen |




Figure 1: Robot coordinate system in XYZ mode

2.2 Robot Control

The robot station is controlled by a controller that is programmed via the Melfa programming language.

| Controller | |
|------------|-------------------|
| Device: | Robot Controller |
| ID: | CR750-D |
| MAC: | |
| IP: | 192.168.162.82/25 |

The user can execute commands and movements of the robot station via an OPC Ua server running on a Raspberry Pi.

| OPC UA Gateway | |
|----------------|-------------------|
| Device: | RaspberryPi 3 |
| ID: | BCM2835 (a02082) |
| MAC: | b8:27:eb:09:db:ca |
| IP: | 192.168.162.84/25 |

2.3 Sensors/Actuators

Inputs and outputs are addressed via their unique index in Melfa and subsequently in the OPC Ua interface.

| Index | Beschreibung |
|-------|--|
| 1 | Modul Roboterhandling - Werkstück ausgerichtet |
| 2 | Modul Roboterhandling - Werkstück in Abholposition |
| 3 | Bedienfeld - Start (Schließer) |
| 4 | Bedienfeld - Stopp (Öffner) |
| 5 | Bedienfeld - Reset (Schließer) |
| 7 | Bedienfeld - COM Brücke (I7) |
| 8 | Modul Robotertermontage (Federmagazin) - Schieber eingefahren |
| 9 | Modul Robotertermontage (Federmagazin) - Schieber ausgefahren |
| 10 | Modul Robotertermontage (Federmagazin) - Feder vorhanden |
| 12 | Modul Robotertermontage (Deckelmagazin) - Schieber eingefahren |
| 13 | Modul Robotertermontage (Deckelmagazin) - Schieber ausgefahren |
| 15 | Modul Robotertermontage (Deckelmagazin) - Deckel auf Ablage |
| 900 | Modul Roboter (Hand) - Teil nicht schwarz |

| Index | Beschreibung |
|-------|--|
| 0 | Bedienfeld - Start (LED) |
| 1 | Bedienfeld - Reset (LED) |
| 2 | Bedienfeld - Q1 (LED) |
| 3 | Bedienfeld - Q2 (LED) |
| 4 | Bedienfeld - COM Brücke (Q4) |
| 8 | Modul Robotertermontage (Federmagazin) - Schieber ausfahren |
| 12 | Modul Robotertermontage (Deckelmagazin) - Schieber ausfahren |

3 Handover Protocol

Since the robot station by itself is capsuled no handover protocol between the internal modules is necessary. The robot can however be used in combination with other stations via the OPC Ua interfaced that was created in this phase. A Raspberry Pi is used as a OPC Ua server connected to the robot controller via a telnet interface. This setup provides the following methods:

| Method | Function |
|---------------------------|---|
| OpenGripper() | Opens the multi function gripper |
| CloseGripper() | Closes the multi function gripper |
| Move(X,Y,Z,A,B,C) | Moves the robot arm to the given coordinates |
| GetErrorLog(NUMLOGS) | Returns the last NUMLOGS errors that occurred |
| ReadInput(INDEX) | Returns the state of the input at the given index |
| WriteOutput(INDEX, STATE) | Sets the output at the given INDEX to the given STATE |
| ResetError() | Resets the robot controller from the error state |